










Maintenance Schedule

Items	Pre-ride Check P. 34	Frequency *1									Annual Check	Regular Replace	Refer to page		
		× 1,000 km	1	6	12	18	24	30	36						
		× 1,000 mi	0.6	4	8	12	16	20	24						
Fuel Line				I	I	I	I	I	I	I	I			-	
Fuel Level		I												-	
Throttle Operation		I		I	I	I	I	I	I	I	I			55	
Air Cleaner *2							R				R			-	
Crankcase Breather*3				C	C	C	C	C	C	C	C			41	
Spark Plug				I	R	I	R	I	R					-	
Valve Clearance				I	I	I	I	I	I	I	I			-	
Engine Oil		I	R	R	R	R	R	R	R	R	R	R		48	
Engine Oil Strainer Screen						C			C		C			-	
Engine Oil Centrifugal Filter						C			C		C			-	
Engine Idle Speed			I	I	I	I	I	I	I	I	I			-	
Drive Chain		I		Every 500 km (300 mi): I L											54

Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled.
Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your vehicle serviced by your dealer.

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
C : Clean
L : Lubricate
R : Replace

Items	Pre-ride Check P. 34	Frequency *1									Annual Check	Regular Replace	Refer to page
		x 1,000 km	1	6	12	18	24	30	36				
		x 1,000 mi	0.6	4	8	12	16	20	24				
Brake Fluid *4	I			I	I	I	I	I	I	I	I	2 Years	50
Brake Pads Wear	I			I	I	I	I	I	I	I	I		51
Brake System			I	I	I	I	I	I	I	I	I		50
Brakelight Switch				I	I	I	I	I	I	I	I		52
Headlight Aim				I	I	I	I	I	I	I	I		-
Lights/Horn	I												-
Clutch System	W		I	I	I	I	I	I	I	I	I		-
Side Stand				I	I	I	I	I	I	I	I		53
Suspension	W			I	I	I	I	I	I	I	I		-
Nuts, Bolts, Fasteners	W		I		I		I		I		I		-
Wheels/Tyres	W	I		I	I	I	I	I	I	I	I		41
Steering Head Bearings	W				I		I		I		I		-

Notes:

*1 : At higher odometer reading, repeat at the frequency interval established here.

*2 : Service more frequently when riding in unusually wet or dusty areas.

*3: Service more frequently when riding in rain or at full throttle.

*4 : Replacement requires mechanical skill.