










Items	Pre-ride Check P. 37	Frequency *1								Annual Check	Regular Replace	Refer to page
		x 1,000 km	1	6	12	18	24	30	36			
		x 1,000 mi	0.6	4	8	12	16	20	24			
Fuel Line				I	I	I	I	I	I	I		-
Fuel Level		I										28
Throttle Operation		I		I	I	I	I	I	I	I		65
Air Cleaner *2						R				R		-
Crankcase Breather *3				C	C	C	C	C	C	C		44
Spark Plug				I	R	I	R	I	R			-
Valve Clearance				I	I	I	I	I	I	I		-
Engine Oil		I	R	R	R	R	R	R	R	R	R	54
Engine Oil Strainer Screen						C		C		C		-
Engine Oil Centrifugal Filter						C		C		C		-
Engine Idle Speed			I	I	I	I	I	I	I	I		-

Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your vehicle serviced by your dealer.

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- C** : Clean
- L** : Lubricate
- R** : Replace

Maintenance Schedule

Items	Pre-ride Check P. 37	Frequency *1								Annual Check	Regular Replace	Refer to page	
		× 1,000 km	1	6	12	18	24	30	36				
		× 1,000 mi	0.6	4	8	12	16	20	24				
Drive Chain	I		Every 500 km (300 mi): I L										64
Brake Fluid *4	I			I	I	I	I	I	I	I	I	2 Years	56
Brake Shoes/Pads Wear	I			I	I	I	I	I	I	I			57, 61
Brake System	I		I	I	I	I	I	I	I	I			37
Brakelight Switch				I	I	I	I	I	I	I			62
Headlight Aim				I	I	I	I	I	I	I			–
Lights/Horn	I												–
Clutch System	W		I	I	I	I	I	I	I	I			–
Side Stand				I	I	I	I	I	I	I			63
Suspension	W			I	I	I	I	I	I	I			–
Nuts, Bolts, Fasteners	W		I		I		I		I				–
Wheels/Tyres	I			I	I	I	I	I	I	I			44
Steering Head Bearings	W				I		I		I				–

Notes:

*1 : At higher odometer reading, repeat at the frequency interval established here.

*2 : Service more frequently when riding in unusually wet or dusty areas.

*3 : Service more frequently when riding in rain or at full throttle.

*4 : Replacement requires mechanical skill.