

| Items                       |   | Pre-ride Check<br>P. 44 | Frequency *1 |     |   |    |    |    |    |    | Annual Check | Regular Replace | Refer to page |
|-----------------------------|---|-------------------------|--------------|-----|---|----|----|----|----|----|--------------|-----------------|---------------|
|                             |   |                         | × 1,000 km   | 1   | 6 | 12 | 18 | 24 | 30 | 36 |              |                 |               |
|                             |   |                         | × 1,000 mi   | 0.6 | 4 | 8  | 12 | 16 | 20 | 24 |              |                 |               |
| Fuel Line                   | 🔧 |                         |              |     | I |    | I  |    | I  | I  |              | -               |               |
| Fuel Level                  |   | I                       |              |     |   |    |    |    |    |    |              | -               |               |
| Throttle Operation          | 🔧 | I                       |              |     | I |    | I  |    | I  | I  |              | 77              |               |
| Air Cleaner *2              | 🔧 |                         |              |     |   | R  |    |    |    | R  |              | 54              |               |
| Crankcase Breather *3       |   |                         |              | C   | C | C  | C  | C  | C  |    |              | 78              |               |
| Spark Plug                  | 🔧 |                         |              |     |   |    |    | R  |    |    |              | -               |               |
| Valve Clearance             | 🔧 |                         |              |     |   |    |    | I  |    |    |              | -               |               |
| Engine Oil                  |   | I                       |              | R   |   | R  |    | R  |    | R  | R            | 62              |               |
| Engine Oil Filter           |   |                         |              | R   |   |    |    | R  |    |    |              | 62              |               |
| Engine Idle Speed           | 🔧 |                         |              |     | I |    | I  | I  |    | I  | I            | -               |               |
| Radiator Coolant *4         |   | I                       |              |     | I |    | I  | I  |    | I  | I            | 3 Years         | 64            |
| Cooling System              | 🔧 |                         |              |     | I |    | I  | I  |    | I  | I            | -               |               |
| Secondary Air Supply System | 🔧 |                         |              |     |   |    |    | I  |    |    |              | -               |               |


### Maintenance Level

- 🔧 : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
- 🔧✂️ : Technical. In the interest of safety, have your motorcycle serviced by your dealer.

### Maintenance Legend

- I : Inspect (clean, adjust, lubricate, or replace, if necessary)
- L : Lubricate
- R : Replace
- C : Clean

## Maintenance Schedule

| Items              | Pre-ride Check<br>P. 44   | Frequency *1 |                              |   |    |    |    |    |    | Annual Check | Regular Replace | Refer to page |    |
|--------------------|---|--------------|------------------------------|---|----|----|----|----|----|--------------|-----------------|---------------|----|
|                    |   | × 1,000 km   | 1                            | 6 | 12 | 18 | 24 | 30 | 36 |              |                 |               |    |
|                    |   | × 1,000 mi   | 0.6                          | 4 | 8  | 12 | 16 | 20 | 24 |              |                 |               |    |
| Drive Chain        | I   |              | Every 1,000 km (600 mi): I L |   |    |    |    |    |    |              |                 |               | 70 |
| Drive Chain Slider |   |              |                              | I |    | I  |    | I  |    |              |                 | 73            |    |
| Brake Fluid *4     | I   |              |                              | I | I  | I  | I  | I  | I  | I            | 2 Years         | 66            |    |
| Brake Pads Wear    | I   |              |                              | I | I  | I  | I  | I  | I  | I            |                 | 67            |    |
| Brake System       |   |              |                              |   | I  |    | I  |    | I  | I            |                 | 66            |    |
| Brakelight Switch  |   |              |                              |   | I  |    | I  |    | I  | I            |                 | 68            |    |
| Headlight Aim      |   |              |                              |   | I  |    | I  |    | I  | I            |                 | 79            |    |
| Lights/Horn        | I   |              |                              |   |    |    |    |    |    |              |                 | -             |    |
| Engine Stop Switch | I   |              |                              |   |    |    |    |    |    |              |                 | -             |    |
| Clutch System      | I   |              |                              | I | I  | I  | I  | I  | I  | I            |                 | 74            |    |
| Side Stand         | I   |              |                              |   | I  |    | I  |    | I  | I            |                 | 69            |    |
| Suspension         |  |              |                              |   | I  |    | I  |    | I  | I            |                 | -             |    |




### Notes:

\*1 : At higher odometer readings, repeat at the frequency interval established here.

\*2 : Service more frequently when riding in unusually wet or dusty areas.

\*3 : Service more frequently when riding in rain or at full throttle.

\*4 : Replacement requires mechanical skill.

| Items                  |   | Pre-ride<br>Check<br>☑ P. 44 | Frequency *1 |     |   |    |    |    |    |    | Annual<br>Check | Regular<br>Replace | Refer to<br>page |
|------------------------|---|------------------------------|--------------|-----|---|----|----|----|----|----|-----------------|--------------------|------------------|
|                        |   |                              | × 1,000 km   | 1   | 6 | 12 | 18 | 24 | 30 | 36 |                 |                    |                  |
|                        |   |                              | × 1,000 mi   | 0.6 | 4 | 8  | 12 | 16 | 20 | 24 |                 |                    |                  |
| Nuts, Bolts, Fasteners |  |                              |              |     | ☑ |    | ☑  |    | ☑  | ☑  |                 | -                  |                  |
| Wheels/Tyres           |  | ☑                            |              |     | ☑ |    | ☑  |    | ☑  | ☑  |                 | 51                 |                  |
| Steering Head Bearings |  |                              |              |     | ☑ |    | ☑  |    | ☑  | ☑  |                 | -                  |                  |