

Maintenance Schedule

Malaysia









Items	Pre-ride Check P. 82	Frequency *1									Annual Check	Regular Replace	Refer to page
		× 1,000 km	1	6	12	18	24	30	36				
		× 1,000 mi	0.6	4	8	12	16	20	24				
Fuel Line					I		I		I	I		-	
Fuel Level	I											-	
Throttle Operation		I			I		I		I	I		108	
Air Cleaner *2						R			R			91	
Crankcase Breather *3				C	C	C	C	C	C			109	
Spark Plug					R		R		R			96	
Valve Clearance							I					-	
Engine Oil	I		R		R		R		R	R		99	
Engine Oil Filter			R				R					99	
Engine Idle Speed					I		I		I	I		-	
Radiator Coolant *4	I				I		I		I	I	3 Years	102	
Cooling System					I		I		I	I		-	
Secondary Air Supply System							I					-	

Maintenance Level

- : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
- : Technical. In the interest of safety, have your scooter serviced by your dealer.

Maintenance Legend

- I : Inspect (clean, adjust, lubricate, or replace, if necessary)
- R : Replace
- C : Clean

Items	Pre-ride Check P. 82	Frequency *1								Annual Check	Regular Replace	Refer to page
		× 1,000 km	1	6	12	18	24	30	36			
		× 1,000 mi	0.6	4	8	12	16	20	24			
Drive Belt					I		R		I			-
Belt Case Air Cleaner					C		C		C			-
Final Drive Oil *4											2 Years	-
Brake Fluid *4		I		I	I	I	I	I	I	I	2 Years	105
Brake Pads Wear		I		I	I	I	I	I	I	I		106
Brake System					I		I		I	I		82
Headlight Aim					I		I		I	I		110
Lights/Horn		I										-
Engine Stop Switch		I										-
Clutch Shoes Wear					I		I		I			-
Side Stand		I			I		I		I	I		107
Suspension					I		I		I	I		-
Nuts, Bolts, Fasteners					I		I		I	I		-
Wheels/Tyres		I			I		I		I	I		88
Steering Head Bearings					I		I		I	I		-

Notes:

*1: At higher odometer reading, repeat at the frequency interval established here.

*2: Service more frequently when riding in unusually wet or dusty areas.

*3: Service more frequently when riding in rain or at full throttle.

*4: Replacement requires mechanical skill.